







Model Number

NJ2-11-N-G

Features

- 2 mm flush
- Usable up to SIL 2 acc. to IEC 61508

Tec	hnical	Data

General specifications Switching function Normally closed (NC)

Output type		NAMUR
Rated operating distance	s _n	2 mm
Installation		flush
Assured operating distance	sa	0 1.62 mm
Actual operating distance	s _r	1.8 2.2 mm
Reduction factor r _{Al}		0.4
Reduction factor r _{Cu}		0.3
Reduction factor r ₃₀₄		0.85

 \leq 1 mA

Nominal ratings 8.2 V (R $_{\rm i}$ approx. 1 k Ω) 0 ... 3000 Hz Nominal voltage Switching frequency Hysteresis 0.5 ... 3.5 typ. 2 %

Current consumption Measuring plate not detected \geq 3 mA

Measuring plate detected Functional safety related parameters

MTTF_d
Mission Time (T_M)
Diagnostic Coverage (DC) 5887 a 20 a 0 %

Ambient conditions Ambient temperature -25 ... 100 °C (-13 ... 212 °F)

Mechanical specifications

cable PVC , 2 m 0.34 mm² Connection type Core cross-section Housing material Stainless steel 1.4305 / AISI 303 Sensing face PVDF Degree of protection IP68 Cable

Bending radius
General information > 10 x cable diameter

Use in the hazardous area see instruction manuals 1G; 2G; 3G; 1D; 3D Category

Compliance with standards and directives

Standard conformity

NAMUR EN 60947-5-6:2000 IEC 60947-5-6:1999 EN 60947-5-2:2007 Standards IEC 60947-5-2:2007

Approvals and certificates


FM approval

Control drawing 116-0165


UL approval cULus Listed, General Purpose

CCC approval CCC approval / marking not required for products rated ≤36 V

Dimensions



Electrical Connection



Equipment protection level Ga

Instruction

Device category 1G

EC-Type Examination Certificate

CE marking

ATEX marking Standards

Appropriate type

Effective internal inductivity C_i Effective internal inductance

Ambient temperature

Installation, commissioning

Maintenance

Special conditions

Protection from mechanical danger

Electrostatic charge

Manual electrical apparatus for hazardous areas

for use in hazardous areas with gas, vapour and mist

PTB 00 ATEX 2048 X

C€0102

(Ex) II 1G Ex ia IIC T6...T1 Ga The Ex-related marking can also be printed on the

EN 60079-0:2012+A11:2013 EN 60079-11:2012 Ignition protection "Intrinsic safety" Use is restricted to the following stated conditions

NJ 2-11-N-G..

≤ 30 nF; a cable length of 10 m is considered.

≤ 50 µH; a cable length of 10 m is considered.

The apparatus has to be operated according to the appropriate data in the data sheet and in this instruction manual.

The EU-type examination certificate has to be observed. The special conditions must be adhered to!

The ATEX directive and therefore the EU-type examination certificates apply in general only to the use of electrical apparatus under atmospheric conditions

The use in ambient temperatures of > 60 °C was tested with regard to hot surfaces by the mentioned certification authority.

If the equipment is not used under atmospheric conditions, a reduction of the permissible minimum ignition energies may have to be taken into consideration

Details of the correlation between the type of circuit connected, the maximum permissible ambient temperature, the temperature class, and the effective internal reactance values can be found on the EC-type examination certificate. Note: Use the temperature table for category 1 $\stackrel{\text{\tiny !!!}}{\text{\tiny !!!}}$ The 20 % reduction in accordance with EN 1127-1 has already been applied to the temperature table for category 1.

Laws and/or regulations and standards governing the use or intended usage goal must be observed.

The intrinsic safety is only assured in connection with an appropriate related apparatus and according to the proof of intrinsic safety.

The associated apparatus must satisfy the requirements of category ia

Due to the possible danger of ignition, which can arise due to faults and/or transient currents in the equipotential bonding system, galvanic isolation of the power supply and signal circuit is preferable. Associated apparatus without electrical isolation must only be used if the appropriate requirements of IEC 60079-14 are met. If the Exrelated marking is printed only on the supplied label, then this must be attached in the immediate vicinity of the sensor. The sticking surface for the label must be clean and free from grease. The attached label must be legible and indelible, including in the event of possible chemical corrosion.

No changes can be made to apparatus, which are operated in hazardous areas. Repairs to these apparatus are not possible.

The connecting parts of the sensor must be set up in such a way that degree of protection IP20, in accordance with IEC 60529, is achieved as a minimum.

When using the device in a temperature range of -60 °C to -20 °C, protect the sensor against the effects of impact by installing an additional enclosure.

The information regarding the minimum ambient temperature for the sensor as provided in the datasheet must also be observed.

Electrostatic charges on the metal housing components must be avoided. Dangerous electrostatic charges on the metal housing components can be avoided by incorporating these components in the equipotential bonding.

PEPPERL+FUCHS

Equipment protection level Gb

Instruction

Device category 2G

EC-Type Examination Certificate

CE marking

ATEX marking

Standards

Appropriate type

Effective internal inductivity
Effective internal inductance

Ci

General

Maximum permissible ambient temperature Tamb

Installation, commissioning

Maintenance

Special conditions

Protection from mechanical danger

Electrostatic charge

Manual electrical apparatus for hazardous areas

for use in hazardous areas with gas, vapour and mist PTB 00 ATEX 2048 X

€0102

(x) II 1G Ex ia IIC T6...T1 Ga The Ex-related marking can also be printed on the enclosed label.

EN 60079-0:2012+A11:2013 EN 60079-11:2012 Ignition protection "Intrinsic safety" Use is restricted to the following stated conditions

NJ 2-11-N-G...

≤ 30 nF; a cable length of 10 m is considered.

 $\leq 50~\mu H$; a cable length of 10 m is considered.

The apparatus has to be operated according to the appropriate data in the data sheet and in this instruction manual. The EU-type examination certificate has to be observed. The special conditions must be adhered to!

The ATEX directive and therefore the EU-type examination certificates apply in general only to the use of electrical apparatus under atmospheric conditions. The use in ambient temperatures of $> 60~^{\circ}\text{C}$ was tested with regard to hot surfaces

The use in ambient temperatures of > 60 °C was tested with regard to hot surfaces by the mentioned certification authority.

If the equipment is not used under atmospheric conditions, a reduction of the permissible minimum ignition energies may have to be taken into consideration.

Details of the correlation between the type of circuit connected, the maximum permissible ambient temperature, the temperature class, and the effective internal reac-

tance values can be found on the EC-type examination certificate.

Laws and/or regulations and standards governing the use or intended usage goal must be observed. The intrinsic safety is only assured in connection with an appropriate related apparatus and according to the proof of intrinsic safety.

priate related apparatus and according to the proof of infinistic safety. If the Ex-related marking is printed only on the supplied label, then this must be attached in the immediate vicinity of the sensor. The sticking surface for the label must be clean and free from grease. The attached label must be legible and indelible, including in the event of possible chemical corrosion.

No changes can be made to apparatus, which are operated in hazardous areas. Repairs to these apparatus are not possible.

The connecting parts of the sensor must be set up in such a way that degree of protection IP20, in accordance with IEC 60529, is achieved as a minimum.

When using the device in a temperature range of -60 $^{\circ}$ C to -20 $^{\circ}$ C, protect the sensor against the effects of impact by installing an additional enclosure. The information regarding the minimum ambient temperature for the sensor as provided in the datasheet must also be observed.

Electrostatic charges must be avoided on the mechanical housing components. Dangerous electrostatic charges on the mechanical housing components can be avoided by incorporating these in the equipotential bonding.

Equipment protection level Gc (nL)

Note

Instruction

Device category 3G (nL)

CE marking

ATEX marking

Standard conformity

Effective internal capacitance Ci Effective internal inductance Li

General

Installation, commissioning

Maintenance

Special conditions

for Pi=34 mW, Ii=25 mA, T6 for Pi=34 mW, Ii=25 mA, T5 for Pi=34 mW, Ii=25 mA, T4-T1 for Pi=64 mW, Ii=25 mA, T6 for Pi=64 mW. Ii=25 mA. T5 for Pi=64 mW, Ii=25 mA, T4-T1 for Pi=169 mW, Ii=52 mA, T6 for Pi=169 mW, Ii=52 mA, T5 for Pi=169 mW, Ii=52 mA, T4-T1 for Pi=242 mW, Ii=76 mA, T6 for Pi=242 mW. li=76 mA. T5 for Pi=242 mW, Ii=76 mA, T4-T1

Protection from mechanical danger

Protection from UV light

Protection of the connection cable

Electrostatic charge

Connection parts

This instruction is only valid for products according to EN 60079-15:2005, valid until 01-May-2013

Manual electrical apparatus for hazardous areas

for use in hazardous areas with gas, vapour and mist

€0102

(x) II 3G Ex nL IIC T6 X The Ex-significant identification is on the enclosed adhesive

EN 60079-15:2005 Ignition protection category "n"

Use is restricted to the following stated conditions

≤ 30 nF; a cable length of 10 m is considered.

 $\leq 50~\mu H$; a cable length of 10 m is considered.

The apparatus has to be operated according to the appropriate data in the data sheet and in this instruction manual. The data stated in the data sheet are restricted by this operating instruction!

The special conditions must be observed!

The ATEX Directive applies only to the use of apparatus under atmospheric condi-

If you use the device outside atmospheric conditions, consider that the permissible safety parameters should be reduced.

Laws and/or regulations and standards governing the use or intended usage goal must be observed. The sensor must only be operated with an energy-limited circuit, which satisfies the requirements of IEC 60079-15. The explosion group depends on the connected and energy-limited supply circuit.

The adhesive label provided must be affixed in the immediate vicinity of the sensor! The surface to which the label is applied must be clean, flat and free from grease! The affixed adhesive label must be readable and durable, taking account of the possibility of chemical corrosion!

No changes can be made to apparatus, which are operated in hazardous areas. Repairs to these apparatus are not possible.

55 °C (131 °F) 52 °C (125.6 °F) 52 °C (125.6 °F) 52 °C (125.6 °F) 44 °C (111.2 °F) 44 °C (111.2 °F) 44 °C (111.2 °F)

The sensor must not be exposed to ANY FORM of mechanical danger. When used in the temperature range below -20 °C the sensor should be protected from knocks by the provision of an additional housing.

The sensor and the connection cable must be protected from damaging UV-radiation. This can be achieved when the sensor is used in internal areas

The connection cable must be prevented from being subjected to tension and torsional loading.

Electrostatic charges must be avoided on the mechanical housing components. Dangerous electrostatic charges on the mechanical housing components can be avoided by incorporating these in the equipotential bonding

The connection parts are to be installed, such that a minimum protection class of IP20 is achieved, in accordance with IEC 60529.



PEPPERL+FUCHS

Equipment protection level Gc (ic)

Instruction

Device category 3G (ic)

Certificate of Compliance

CE marking

ATEX marking

Standards

Effective internal inductivity C: Effective internal inductance

General

Installation, commissioning

Maintenance

Special conditions

for Pi=34 mW, Ii=25 mA, T6 for Pi=34 mW, Ii=25 mA, T5 for Pi=34 mW, Ii=25 mA, T4-T1 for Pi=64 mW li=25 mA T6 for Pi=64 mW, Ii=25 mA, T5 for Pi=64 mW, Ii=25 mA, T4-T1 for Pi=169 mW, Ii=52 mA, T6 for Pi=169 mW. Ii=52 mA. T5 for Pi=169 mW. Ii=52 mA. T4-T1 for Pi=242 mW, Ii=76 mA, T6 for Pi=242 mW, Ii=76 mA, T5 for Pi=242 mW, Ii=76 mA, T4-T1 Protection from mechanical danger

Electrostatic charge

Connection parts

Manual electrical apparatus for hazardous areas

for use in hazardous areas with gas, vapour and mist

PF 13 CERT 2895 X

 ϵ

(a) II 3G Ex ic IIC T6...T1 Gc
The Ex-significant identification is on the enclosed adhesive label

EN 60079-0:2012+A11:2013 EN 60079-11:2012 Ignition protection category "ic" Use is restricted to the following stated conditions

≤ 30 nF; a cable length of 10 m is considered.

 \leq 50 μH ; A cable length of 10 m is considered.

The apparatus has to be operated according to the appropriate data in the data sheet and in this instruction manual. The data stated in the data sheet are restricted by this operating instruction!

The special conditions must be observed!

The ATEX Directive applies only to the use of apparatus under atmospheric condi-

If you use the device outside atmospheric conditions, consider that the permissible safety parameters should be reduced.

Laws and/or regulations and standards governing the use or intended usage goal must be observed. The sensor must only be operated with energy-limited circuits, which satisfy the requirements of IEC 60079-11. The explosion group complies with the connected, supplying, power limiting circuit. If the Ex-relevant identification is printed exclusively on the adhesive label provided, this label must be affixed in the immediate vicinity of the sensor! The background surface to which the adhesivelabel is to be applied must be clean and free from grease! The applied label must be durable and remain legible, with due consideration of the possibility of chemical corrosion!

No changes can be made to apparatus, which are operated in hazardous areas. Repairs to these apparatus are not possible

55 °C (131 °F) 52 °C (125.6 °F) 52 °C (125.6 °F) 52 °C (125.6 °F) 44 °C (111.2 °F) 44 °C (111.2 °F) 44 °C (111.2 °F)

The sensor must not be mechanically damaged.

When used in the temperature range below -20 °C the sensor should be protected from knocks by the provision of an additional housing.

Electrostatic charges must be avoided on the mechanical housing components. Dangerous electrostatic charges on the mechanical housing components can be avoided by incorporating these in the equipotential bonding.

The connection parts are to be installed, such that a minimum protection class of IP20 is achieved, in accordance with IEC 60529.

Equipment protection level Da

Instruction

Device category 1D

EC-Type Examination Certificate CE marking

ATEX marking

Standards

Appropriate type

Effective internal inductivity Ci Effective internal inductance

General

Maximum permissible ambient temperature Tamb

Installation, commissioning

Maintenance

Special conditions

Protection from mechanical danger

Electrostatic charge

Manual electrical apparatus for hazardous areas

for use in hazardous areas with combustible dust

PTB 00 ATEX 2048 X

€0102

(II 1D Ex ia IIIC T135°C Da The Ex-related marking can also be printed on the

EN 60079-0:2012+A11:2013 EN 60079-11:2012 Ignition protection "Intrinsic safety" Use is restricted to the following stated conditions

NJ 2-11-N-G...

 \leq 30 nF; a cable length of 10 m is considered.

 \leq 50 μH ; a cable length of 10 m is considered.

The apparatus has to be operated according to the appropriate data in the data sheet and in this instruction manual.

The EU-type examination certificate has to be observed.

The ATEX directive and therefore the EU-type examination certificates apply in general only to the use of electrical apparatus under atmospheric conditions.

The use in ambient temperatures of > 60 °C was tested with regard to hot surfaces by the mentioned certification authority.

If the equipment is not used under atmospheric conditions, a reduction of the permissible minimum ignition energies may have to be taken into consideration.

Details of the correlation between the type of circuit connected, the maximum permissible ambient temperature, the surface temperature, and the effective internal reactance values can be found on the EC-type-examination certificate.

The maximum permissible ambient temperature of the data sheet must be noted, in addition, the lower of the two values must be maintained.

Laws and/or regulations and standards governing the use or intended usage goal must be observed.

The intrinsic safety is only assured in connection with an appropriate related apparatus and according to the proof of intrinsic safety.

If the Ex-related marking is printed only on the supplied label, then this must be attached in the immediate vicinity of the sensor. The sticking surface for the label must be clean and free from grease. The attached label must be legible and indelible, including in the event of possible chemical corrosion.

No changes can be made to apparatus, which are operated in hazardous areas. Repairs to these apparatus are not possible.

The connecting parts of the sensor must be set up in such a way that degree of protection IP20, in accordance with IEC 60529, is achieved as a minimum.

When using the device in a temperature range of -60 °C to -20 °C, protect the sensor against the effects of impact by installing an additional enclosure. The information regarding the minimum ambient temperature for the sensor as provided in the datasheet must also be observed.

Electrostatic charges must be avoided on the mechanical housing components. Dangerous electrostatic charges on the mechanical housing components can be avoided by incorporating these in the equipotential bonding.

Do not attach the nameplate provided in areas where electrostatic charge can build

Equipment protection level Dc (tD)

This instruction is only valid for products according to EN 61241-0:2006 and EN 61241-1:2004 Note

Note the ex-marking on the sensor or on the enclosed adhesive label

Instruction Manual electrical apparatus for hazardous areas

Device category 3D for use in hazardous areas with non-conducting combustible dust (ϵ)

CE marking

ATEX marking (Ex) II 3D Ex tD A22 IP67 T80°C X

The Ex-significant identification is on the enclosed adhesive label

EN 61241-0:2006, EN 61241-1:2004 Standards

Protection via housing "tD"

Use is restricted to the following stated conditions The apparatus has to be operated according to the appropriate data in the data sheet and in this instruction manual.

The maximum surface temperature has been determined in accordance with method A without a dust layer on the equipment.

The data stated in the data sheet are restricted by this operating instruction!

The special conditions must be adhered to!

Laws and/or regulations and standards governing the use or intended usage goal must be observed. \\ Installation, commissioning

The adhesive label provided must be affixed in the immediate vicinity of the sensor! The surface to which the label is applied must be clean, flat and free from grease! The affixed adhesive label must be readable and durable, taking account of the possi-

bility of chemical corrosion!

Maintenance No changes can be made to apparatus, which are operated in hazardous areas. Repairs to these apparatus are not possible.

Special conditions

General

A minimum series resistance RV is to be provided between the power supply voltage and the proximity switch in accordance Minimum series resistance Ry

with the following list. This can also be assured by using a switch amplifier.

The maximum permissible operating voltage UBmax must be restricted to the values given in the following list. Tolerances are

not permitted. Values can be obtained from the following list, depending on the max. operating voltage Ub max and the minimum series resis-

61 °C (141.8 °F)

tance Rv.

Maximum permissible ambient tempera-

ture $T_{\mbox{Umax}}$

at U_Bmax=9 V, R_V=562 Ω

using an amplifier in accordance with 61 °C (141.8 °F)

EN 60947-5-6

Protection from mechanical danger

Maximum operating voltage U_{Bmax}

Protection from UV light

Protection of the connection cable

Electrostatic charge

The sensor must not be exposed to ANY FORM of mechanical danger.

The sensor and the connection cable must be protected from damaging UV-radiation. This can be achieved when the sensor is

used in internal areas.

The connection cable must be prevented from being subjected to tension and torsional loading.

Electrostatic charges must be avoided on the mechanical housing components. Dangerous electrostatic charges on the

mechanical housing components can be avoided by incorporating these in the equipotential bonding.